



## Hanging Stuff Instructions



2 x end frames



2 x rails with hooks



2 x straps



Mini – 9 poles

Flexi – 9 poles

Maxi – 12 poles\*

\*The Maxi has 2 poles that are longer than the other 10 poles. These poles are to be fixed on the top rung and are to be fixed as the two outside poles



1 x allen key



Once you have checked that all the pieces are included in the box you can start to put together your Hanging Stuff. Please contact [info@hangingstuff.com.au](mailto:info@hangingstuff.com.au) if you are missing any pieces.

### Step 1



Slip the straps over two poles. These will be attached to the bottom rung of the Hanging Stuff

### Step 2



Attach the bottom rung by lying the end frames down on their side. This is the easiest way, particularly if you are putting this together yourself

### Step 3



It's now time to attach the remaining rails.



When attaching the other rails, do not tighten the screws all the way in until you have attached all rails. Once all rails have been attached, then tighten the screws completely in.



#### Step 4



Once you have attached the bottom rungs, you can stand up the Hanging Stuff and attach the remainder of the rails



Ensure that the two rails with the hooks are located on the two top outside rungs



The **Maxi** has 2 poles that are longer than the other 10 poles. These poles are to be fixed on the top rung and are to be fixed as the two outside poles

#### Step 5



Your Hanging Stuff is now ready to use for indoor and outdoor use.